

INSTRUCTIONS FOR INSTALLATION OF LYTEDROP FIXTURE FOR USE WITH 8600 SERIES POWER JACKS ONLY

IS:8626

1189

READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE INSTALLING FIXTURE.

This fixture is intended for installation in accordance with the National Electrical Code and local regulations. To assure full compliance with local codes and regulations, check with your local electrical inspector before installation. To prevent electrical shock, turn off electricity at fuse box before proceeding.

Retain these instructions for maintenance reference.

MOUNTING

1. If used with POINT POWER JACK #8605, use the cap marked "35W MAX." If used with other POWER JACKS, make certain that the STEM BUSHING is removed from the POWER JACK ENTRY (Fig. 2).
2. Screw the JACK ASSEMBLY fully into the POWER JACK (Fig. 2).

INSTRUCTIONS FOR LAMPING

CAUTION: MAKE CERTAIN THAT THE LYTEDROP FIXTURE IS COOL BEFORE HANDLING. SINCE THE LAMP HEATS QUICKLY, MAKE SURE THAT THE POWER IS DISCONNECTED BEFORE INSERTING LAMP INTO THE LAMP SOCKET.

1. SEPARATE

Lift the GLOBE ASSEMBLY (with STYLE JACK SHADE) while rotating to the LEFT until it is released from the LAMP SOCKET ASSEMBLY (Fig. 1).

2. INSTALL LAMP

CAUTION: DO NOT TOUCH THE LAMP WITH BARE HANDS.

Oils from the hands could reduce LAMP life. Use tissue paper or a soft cloth. Insert the LAMP into the SOCKET holes as far as it will go. Pins will be exposed approximately $\frac{1}{8}$ " outside of the SOCKET when fully engaged. No polarity of pins is required.

3. REASSEMBLE (Fig. 2).

